
# Models MB105B-MB110B

# (Floor/ Tabletop Installation Battery Operated) Installation and Maintenance Instructions Questions? Call 610-266-9600 for help

#### For ALL installations:

- Display or sign load MUST be balanced.
- Do NOT use stabilizer casters or wheels to support turntable.

#### Display or Sign mounted on TOP of Rotator:



Model:	Max. Compressive Weight:
MB105B	15 lbs
MB110B	50 lbs

- Larger diameter turntable top may be attached to rotator turntable.
- Weight MUST be balanced (add a counter-weight if needed).
- Speed slows as batteries weaken.
- Keep unit level.
- Not for outdoor use.

## WARNING! Do NOT hang weight from unit.

Hanging weight will cause unit to come apart and fall.

#### Maintenance:

- MB105B: 5 RPM rotation will slow as batteries weaken. Battery life is approximately 60 days.
- MB110B: 2.5 RPM rotation will slow as batteries weaken. Battery life is approximately 25 days.
- No regular maintenance is required for this unit.





Phone: 610-266-9600

Email: info@vuemore.com

www.vuemore.com

## Models MB105B-MB110B

## (Floor/ Tabletop Installation Battery Operated)

## **Electrical Connections**

Questions? Call 610-266-9600 for help

## **MARNING**




Disconnect power before servicing or installing. Do not touch any electrical components while unit is connected to power source.



Keep hands clear while operating. Read installation and maintenance instructions prior to operation.

### Unit without rotating wires/outlet:



- No rotating electrical wires or rotating outlet are available.
- Batteries are not included.
- Remove 6-32 screws from bottom cover to access battery compartment and install batteries.
- To reverse direction, put batteries in backwards.
- Press Switch on unit to start rotating.

Model:	Battery Style
MB105B	2 "D" batteries
MB110B	4 "C" batteries

#### **Limited Warranty:**

The manufacturer warrants the enclosed unit, to the original purchaser only, against factory defects in material and workmanship for twelve months from date of purchase.

Should the unit prove defective or fails to operate properly in use during the warranty period specified above, the manufacturer will repair it or replace it without charge when returned to the factory, <u>freight prepaid</u>, by the original producer. This warranty will be considered void if the product is tampered with, altered, modified, improperly installed or serviced, or damaged through misuse, negligence, or accident. Labor provided by the customer to remove or replace the unit is not covered under this warranty. Warranty covers parts replacement only.

When the warranty is not applicable, the customer will be charged for the cost of repair plus shipping charges. Items damaged in shipping <u>must be returned to the</u> factory in its original container.

The manufacturer shall in no event be liable for inconvenience, or for incidental, consequential, contingent, or any other damages. This warranty is made in lieu of any other express warranty, and, except for the foregoing warranty, which is exclusive, there is no other warranty being made.





Phone: 610-266-9600

Email: info@vuemore.com

www.vuemore.com