



Omni Tent

Product Parts

1. Frame
2. Canopy
3. Frame Wheel (x2)
4. Soft Cover
5. Stake (x8)
6. 4mm Hex Wrench




Display Set-up

Step 1

With a partner, stand across from each other. Grasp a truss at the top of the Frame (1) and the other truss at the bottom, as shown.

Lift slightly off ground and step backwards while squeezing trusses together.


Lift up one side. Grasp the outer or upper leg with one hand and pull out the inner leg with the other. Extend until the leg buttons engage.



NOTE: Lift up the frame 2"-3" off the ground especially in tall grass or sand. Grasp the trusses away from the connections to avoid pinching. Open frame 80%-90%.

Step 2

Unfold the canopy (2) and place on top of the Frame (1). Align and attach the four Hook & Loop corners.




NOTE: Find the corners of the canopy before draping over frame. Do not attach the canopy while the frame is fully extended.

Step 3


Lift up one side of the frame (1) and walk under it.

Place one hand on the upper frame and use the other hand to push the central hub straight up until it clicks into the central pole.



Step 4

To set tent legs to the desired height, lift up one side, grasp the outer or upper leg with one hand and pull out the inner leg with the other. Extend until the button engages.




Note: Do not keep your foot on the footplate while extending the leg. This creates tension that can cause frame damage. Only extend legs after the central lock is engaged. Utilize the various height adjustments to create a level shade.

Omni Tent


Step 5

Insert 2 stakes (5) into the foot of each tent leg.



Frame Wheel Installation


Insert each wheel axel into the hole provided on two of the frame legs. Lock the wheel tight with the provided hex wrench.



Taking Down The Tent


Step 1

Pull up all stakes (5) from the ground. Press the push button to lower all legs.




Step 2

From underneath the canopy, press in the red lock button. Pull down on the central hub until it is separated from the central pole.




Step 3

Remove the Canopy (2) from the Frame. Lift the Frame (1) off the ground 2-3 inches and walk it in from both sides until the Frame is fully closed.



Step 4

Position the Soft Cover (4) strap to align with the 2 wheeled legs. Slide the Soft Cover down over the closed Frame. Zip the Soft Cover closed. Secure the Frame with the buckle and tighten the strap. Insert red plug as shown. Tighten the strap by pulling down the strap loop.



Storage & Care

Store in a cool dry location.
To clean, wipe with damp cloth.

MAKE SURE TO TAKE SPECIAL CARE TO NOT DRAG THE FRAME WHEN SETTING UP OR TAKING DOWN.

We recommend using weight bags or stake kits in all environments. While stakes are ideal to keep your tent secure during all outdoor use, our Sandbag Ballast Kit holds up to 20.6 lbs of sand per ballast and can be easily attached to your tent for additional stability. Additional securing options are available: Steel Tent Leg Ballast Weight (Weights 12 lbs., NOT compatible with our Elite Tent leg, sold individually). Square Plastic Water Weight (Weights 22 lbs. when filled with water, NOT compatible with our Elite Tent leg, sold individually).